

This sheet will allow you to detail any Boeing 707-320B or 320C aircraft. However, please keep in mind that when it comes to variations, the Boeing 707 is king! Therefore it is very important that you have good, detailed references for the exact aircraft you are modeling because not were there different variations between operators, but even within the same airline.

The wings should be painted overall bare-metal. Then apply the large gray pieces as shown above. Some operators had the inspar section painted in coroguard, in that case use sheet FC44-054C to get the coroguard inspar panels. The bottom is in 3 pieces to allow you to glue the engines on the model before painting to fill and sand any gaps. Then place the gray parts as shown. Again, check your references, not all aircraft had the gray parts, or had some pieces of what's depicted in the drawing above.

The cargo door outlines are optional. Place the over-wing escape routes as shown above. Two versions are offered. Again, check photos to be sure you are using the correct version.

A picture is worth a thousand words...









